

FENDER CHAMP II AMPLIFIER (214500)

PARTS LIST

019301 Cabinet w/hdw
019311 Grill frame w/hdw
019767 Upper cabinet back
019766 Lower cabinet back
019170 Handle w/insert
019279 Handle cap
019585 Tolex
018252 Grill cloth
019308 Glide Assy
024695 Corner
011298 Fender Logo
023010 10" Speaker
019118 Power transformer
022913 Output transformer
023564 6V6GTA Tube
013341 7025/12AX7A tube

CAPACITORS

014700 .047 mfd x 125v
023257 .002 10%
004513 .022 mfd x 600v 10%
008159 .1 mfd x 600v 20%
009512 25 mfd x 25v
010543 .01 mfd x 600v 10%
012022 4 mfd x 450v
012754 .047 x 600 wvoc +-10%
014122 70 mfd x 100v
020909 .000047 mfd x 500v
020917 .00025 mfd x 1kv 10%
029320 .0027 x 600 v 10%
094953 .001 mfd x 600v 10%
019128 80 mfd x 40x20x450v
010693 .0012 mfd 600v

RESISTOR

008167 100k x 1w 10%
021162 47 ohm x 1/2w 10%
021204 1k ohm x 1/2w 10%
021212 1.5k ohm x 1/2w 10%
021238 2.7k ohm x 1/2w 10%
021279 10k ohm x 1/2w 10%
021287 15k ohm x 1/2w 10%
021329 56k ohm x 1/2w 10%
021345 100k ohm x 1/2w 10%
021352 470k ohm x 1/2w 10%
021360 1 meg ohm x 1/2w 10%
021378 2.2 meg ohm x 1/2w 10%
021493 220k ohm x 1/2w 10%
031062 4.7k ohm x 1/2w 10%
051136 39k x 1/2w +-10%
073593 12k ohm x 1/2w 10%
021519 1k ohm x 1w 10%
021394 10 meg ohm x 1/2w 10%
021220 2.2k ohm x 1/2w 10%
073502 270 ohm x 1/2w 10%

DIODES

026730 1A x 800v

CONTROLS

013404 250k w/switch (treble)
014038 999k (volume)
021857 250k audio (bass)
021873 100k (Master)
028421 100 ohm (hum balance)

SCREWS

011231 Cabinet back mounting
019277 Speaker mounting
022160 Glide mounting
022103 Corner mounting
022244 Handle mounting
022152 Logo mounting
022236 Chassis strap
084699 Cord clamp

WASHERS

010823 Dress - pilot light
016436 Internal lock (controls)
016469 Internal lock (fuse holder)
022384 Internal lock (hum balance control)
031153 Finish (jack)
043760 Neoprene (fuse holder)
022293 Toggle switch

NUTS


021972 Tee nut (handle mounting)
016352 Jack mounting
019282 Pem (chassis)
022012 Toggle switch mounting
031625 Pilot light holder
031666 Fuse holder mounting

MISCELLANEOUS

013485 Knob (volume, bass, master)
024604 Knob (treble)
019328 Control plate
019329 Rear Chassis Plate
007565 Strain relief bushing (AC cord)
016081 Capacitor clamp
022491 Cable clamp
010766 Line cord
011028 Jack (input)
021956 Jack (output)
021527 Fuse holder
021667 1A slo blo fuse
021741 Pilot light holder
021642 #47 Pilot Light
032219 Pilot light collar
025718 Pilot light jewel
023580 8 pin tube socket
023606 9 pin tube socket
037960 Toggle switch
023598 Tube shield
024679 Chassis strap

EXPORT MODEL ONLY

013002 Line cord
016520 Voltage selector
019119 Power transformer
019332 Rear chassis plate
036788 1-1/2 A fuse
061663 Toggle Switch



Fender Champ II Amplifier Wiring Diagram